



Made in Italy

The products are in compliance with the provisions of the following directives:

- 2004/108 / EC

They respond in full or only to the parts applicable to the following standards:

- - CEI EN 61131-2

The EC Declarations of Conformity can be downloaded from
<http://catalogue.camozzi.com/Downloads.aspx?cat=19>

	Instruction manual Series D multipole size 1	5000026173
		Version 01

Sommary

1. Product identification	4
.....	4
2. General recommendation	5
3. General characteristics and conditions of use	6
4. Product storage and transport	7
5. System description.....	7
6. Installation and commissioning.....	7
6.1 Connecting and signaling elements	8
6.2 Electrical connection	9
6.3 Electrical characteristics.....	10
6.4 Adding a valve position or changing their position.	10
6.7 WLAN connection procedure:.....	12
COILVISION. DESCRIPTION OF THE PREDICTIVE DIAGNOSTIC SYSTEM AND DATA COLLECTION	13
7. CamozziUVIX: Series D configuration	14
7.1 Access to CamozziUVIX:.....	14
.....	14
7.2 : Assignment of the name and group to the Series D valve island.....	15
7.3: General information and valve island status.....	18
7.4 : Commands for configuring the valve island (only with "user" access).....	18
7.4.1 End manual mode:.....	19
7.4.2 Reset slave info: resets the state of health and the number of cycles performed by the valve which is mounted on a sub-base (see paragraph 7.5)	19
7.4.3 Set Digital Output: allows remote operation of the single coil of the valve island.	20
7.5 General information and status of the individual solenoid coils.....	20
7.6 Configurazione dei parametri della sottobase (solo con accesso "user").....	21
7.6.1 Set Alarms Enable: Enabling of the single alarm for each valve position.....	22
6.5.1 Alarm mode:.....	22
8. FAULT IDENTIFICATION	23
9. USE	25
10. USE LIMITATION	25

	Instruction manual Series D multipole size 1	5000026173
		Version 01

11.	MAINTENANCE	25
12.	ECOLOGICAL INFORMATION.....	26
13.	Contacts	26
	<i>Product Certification</i>	26
	<i>Technical assistance</i>	26

1. Product identification



Conversion table for the production date.

86-1400-0001 Rev. D

Leaf 02 / 02

Position 1 and 2: n° of the week.

01	14	27	40
02	15	28	41
03	16	29	42
04	17	30	43
05	18	31	44
06	19	32	45
07	20	33	46
08	21	34	47
09	22	35	48
10	23	36	49
11	24	37	50
12	25	38	51
13	26	39	52

Example of composition.

03P

Description:

03	Week n° 03
P	Year 2010

Position 3: One letter for the present Year.

A		1996	2021	2046
B		1997	2022	2047
C		1998	2023	2048
D		1999	2024	2049
E		2000	2025	2050
F		2001	2026	2051
G		2002	2027	2052
H		2003	2028	2053
I		2004	2029	2054
K		2005	2030	2055
L		2006	2031	2056
M		2007	2032	2057
N		2008	2033	2058
O		2009	2034	2059
P		2010	2035	2060
Q		2011	2036	2061
R		2012	2037	2062
S	1988	2013	2038	2063
T	1989	2014	2039	2064
U	1990	2015	2040	2065
V	1991	2016	2041	2066
W	1992	2017	2042	2067
X	1993	2018	2043	2068
Y	1994	2019	2044	2069
Z	1995	2020	2045	2070

Managing authority:

Industrial Engineering

Date:

9 April 2010

Created by:

Marco Bontempi

Approved by:

Bruno Ghizzardi

	Instruction manual Series D multipole size 1	5000026173
		Version 01

2. General recommendation

Please respect the recommendations for safe use described in this document.


- Some hazards can be associated with the product only after it has been installed on the machine / equipment. The end user is responsible for identifying these dangers and reducing the risks associated with them.
- The products covered by this manual can be used in circuits that must comply with EN ISO 13849-1.
- For information regarding the reliability of the components, contact Camozzi.
- Before using the product, carefully read the information contained in this document.
- Keep this document in a safe and handy place throughout the life cycle of the product.
- Transfer this document to any subsequent holder or user.
- The instructions contained in this manual and further information can be found using the following references:

o Website <http://www.camozzi.com>

o Camozzi general catalog

o Technical assistance service

- Assembly and commissioning must only be carried out by qualified and authorized personnel, according to these instructions.
- It is the responsibility of the system / machinery designer to correctly choose the most appropriate component according to the required use.
- The use of suitable protections is recommended to minimize the risk of personal injury.
- For all those situations of use not covered in this manual and in situations where damage to property, persons or animals could be caused, contact Camozzi first.
- Do not carry out unauthorized modifications on the product. In this case, any damage caused to people or animals is to be considered the responsibility of the user.
- It is recommended to comply with all the safety regulations affected by the product.
- Do not intervene on the machine / system unless after checking that the working conditions are safe.
- Before installation or maintenance, make sure that the specific safety lockout positions are activated, then cut off the power supply (if necessary) and the pressure supply of the system, discarding all the residual compressed air present in the system and deactivating the residual energy stored in springs, condensers, receptacles and gravity.
- After installation or maintenance, it is necessary to reconnect the pressure and electrical supply (if necessary) of the system and check the regular operation and tightness of the product. In the event of a leak or malfunction, the product must not be put into operation.
- The product can be put into operation only in compliance with the specifications indicated, if these specifications are not respected the product can be put into operation only after authorization by Camozzi.
- Avoid covering the appliances with paints or other substances that reduce heat dissipation.

	Instruction manual Series D multipole size 1	5000026173
		Version 01


3. General characteristics and conditions of use

PNEUMATIC

Valve type	Spool with seals
	5/2 monostable e bistable
Valve functions	2x3/2 NC 2x3/2 NO 1x3/2 NC+1x3/2 NO
	5/3 CC – CP – CO
Material	spool: AL - spool seals: HNBR - other seals: NBR - metal body - technopolymer bottoms and sub-base
Connection	outlet 2 e 4 thread or bushings, tube size variable according to pitch
Temperature	0 ÷ 50 °C
Air Characteristics	filtered and non-lubricated compressed air in class 6.4.4 according to ISO 8573-1: 2010. If lubrication is required, use only oils with max. Viscosity. 32 Cst and the version with external servo pilot. The air quality to the servo pilot must be in class 7.4.4 according to ISO 8573-1: 2010 (do not lubricate).
Valve Size	10 mm
Working pressure	-0.9 ÷ 10 bar
	2 ÷ 7 bar
Pilot pressure	3.5 ÷ 7 bar (con pressione di lavoro superiore ai 6 bar per la versione 2x3/2)
Valve flow	250 NI/min (10.5 mm)
Mounting position	everyone
IP protection	IP65

ELETTRIC

D-Sub Connector	25 o 44 poles
Max Power consumption	1,5 A
Supply voltage	24 V DC +/-10%
Max coils	22 coils on 11 valve positions (with 25-pin Sub-D connector) 38 coils on 19 valve positions (with 44-pin Sub-D connector)
Switching valve	Yellow led
Fault detection led	Red led
Operation status LED	Green led - WLAN operation, power supply present
Electropilot power	1W (Power reduction to 0,3W after 100 ms)

	Instruction manual Series D multipole size 1	5000026173
		Version 01

4. Product storage and transport

- Adopt all measures possible to avoid accidental damage to the product during transport, and when available use the original packaging.
- Observe the specified storage temperature range of $-10 \div 50$ °C.

5. System description

The D Series is a valve island equipped with COILVISION technology that allows you to monitor and predict the state of wear and efficiency of some parts of the individual solenoid valves. Through this monitoring and predictive diagnostics system it is possible, for example, to know the electricity consumption and the possible overheating of the coil. The detected data, alarms and health status can be transmitted via cable to a PLC or via WLAN to an IIoT Gateway for subsequent sending to the Cloud. The D Series is suitable for use in applications with limited installation space without penalizing the flow rate.

Available with connection integrated in a D-sub connector, it allows to cover the needs of all industrial applications.


COILVISION technology has been developed to constantly monitor the functional parameters of the electropilot which operates the spool via air. Each actuation of the electropilot, in different cyclic configurations and environmental conditions, is analyzed to acquire information which, processed by software algorithms, allows to diagnose and predict the health of the component.

6. Installation and commissioning

- During the unpacking phase, be very careful not to damage the product.
- Check for damage due to transportation or storage of the product.
- Separate the packaging materials in order to allow their recovery or disposal in compliance with the regulations in force in your country.
- Before putting the component into operation, check that the declared characteristics and performances correspond to those required.
- During the installation of the component, provide for specific surge protection devices.
- During the installation of the component, check that there is no danger due to mechanical movements.
- Install the component in an area where the set-up and maintenance phases are easily performed and cannot create dangers for the operator.
- Close any unused connections with the appropriate covers or protective caps, in the case of the 3/5 and 82/84 exhaust channels with appropriate silencers.
- The components must be fixed correctly, using the appropriate anchors, where available, and checking that the fixing remains effective even in the presence of high cycles or strong vibrations. In presenza di forti vibrazioni prevedere appositi dispositivi/sistemi in grado di attutirne l'effetto sul componente.
- Provide for the installation of dehumidifiers in order to avoid the formation of humidity and condensation in the internal components.



- If the device is used to operate an actuator whose accidental movement can generate a hazard, provide for appropriate locking devices for the moving part of the actuator.
- Make sure the connectors are connected and fastened correctly.
- Use only power supplies capable of ensuring safe electrical disconnection of the voltage supply according to IEC 742 / EN 60742 / VDE 0551 with a minimum insulation resistance of 4 kV Protected Extra Low Voltage (PELV).
- It is the user's task to adopt the necessary measures to prevent damage to the system caused by non-periodic overvoltage peaks on the power lines following power cuts on high energy equipment.
- Voltage interruptions are allowed according to the PS2 severity level.


6.1 Connecting and signaling elements



	Instruction manual Series D multipole size 1	5000026173
		Version 01

6.2 Electrical connection

25 poles	Pin	Cables Color G25X1	Function	44 poles	Pin	Cables Color G44X1	Function
	1	WHITE	Valve 1 – Solenoid 14		1	WHITE	Valve 1 – Solenoid 14
	2	BROWN	Valve 1 – Solenoid 12		2	BROWN	Valve 1 – Solenoid 12
	3	GREEN	Valve 2 – Solenoid 14		3	GREEN	Valve 2 – Solenoid 14
	4	YELLOW	Valve 2 – Solenoid 12		4	YELLOW	Valve 2 – Solenoid 12
	5	GREY	Valve 3 – Solenoid 14		5	GREY	Valve 3 – Solenoid 14
	6	PINK	Valve 3 – Solenoid 12		6	PINK	Valve 3 – Solenoid 12
	7	BLUE	Valve 4 – Solenoid 14		7	BLUE	Valve 4 – Solenoid 14
	8	RED	Valve 4 – Solenoid 12		8	RED	Valve 4 – Solenoid 12
	9	BLACK	Valve 5 – Solenoid 14		9	BLACK	Valve 5 – Solenoid 14
	10	VIOLET	Valve 5 – Solenoid 12		10	VIOLET	Valve 5 – Solenoid 12
	11	GREY/PINK	Valve 6 – Solenoid 14		11	GREY/PINK	Valve 6 – Solenoid 14
	12	RED/BLUE	Valve 6 – Solenoid 12		12	RED/BLUE	Valve 6 – Solenoid 12
	13	WHITE/GREEN	Valve 7 – Solenoid 14		13	WHITE/GREEN	Valve 7 – Solenoid 14
	14	BROWN/GREEN	Valve 7 – Solenoid 12		14	BROWN/GREEN	Valve 7 – Solenoid 12
	15	WHITE/YELLOW	Valve 8 – Solenoid 14		15	WHITE/YELLOW	Valve 8 – Solenoid 14
	16	YELLOW/BROWN	Valve 8 – Solenoid 12		16	YELLOW/BROWN	Valve 8 – Solenoid 12
	17	WHITE/GREY	Valve 9 – Solenoid 14		17	WHITE/GREY	Valve 9 – Solenoid 14
	18	GREY/BROWN	Valve 9 – Solenoid 12		18	GREY/BROWN	Valve 9 – Solenoid 12
	19	WHITE/PINK	Valve 10 – Solenoid 14		19	WHITE/PINK	Valve 10 – Solenoid 14
	20	PINK/BROWN	Valve 10 – Solenoid 12		20	PINK/BROWN	Valve 10 – Solenoid 12
	21	WHITE/BLUE	Valve 11 – Solenoid 14		21	WHITE/BLUE	Valve 11 – Solenoid 14
	22	BROWN/BLUE	Valve 11 – Solenoid 12		22	BROWN/BLUE	Valve 11 – Solenoid 12
	23	WHITE/RED	Diagnostic output		23	WHITE/RED	Valve 12 – Solenoid 14
	24	BROWN/RED	+ 24Vdc		24	BROWN/RED	Valve 12 – Solenoid 12
	25	WHITE/BLACK	Negative Common		25	BIANCO/NERO	Valve 13 – Solenoid 14
NOTE: It is suggested to connect all the not used wired to the same negative common of the power supply (Pin 25 for 25 pins D-sub version and 43/44 pins fot the 44 pins D-sub version)					26	BROWN/BLACK	Valve 13 – Solenoid 12
					27	GREY/GREEN	Valve 14 – Solenoid 14
					28	YELLOW/GREY	Valve 14 – Solenoid 12
					29	PINK/GREEN	Valve 15 – Solenoid 14
					30	YELLOW/PINK	Valve 15 – Solenoid 12
					31	GREEN/BLUE	Valve 16 – Solenoid 14
					33	YELLOW/BLUE	Valve 16 – Solenoid 12
					33	GREEN/RED	Valve 17 – Solenoid 14
					34	YELLOW/RED	Valve 17 – Solenoid 12
					35	GREEN/BLACK	Valve 18 – Solenoid 14
					36	YELLOW/BLACK	Valve 18 – Solenoid 12
					37	GREY/BLUE	Valve 19 – Solenoid 14
					38	PINK/BLUE	Valve 19 – Solenoid 12
					39	GREY/RED	Diagnostic output
					40	PINK/RED	Not used
					41	GREY/BLACK	+24 Vdc
					42	PINK/BLACK	
					43	BLUE/BLACK	Negative common
					44	RED/BLACK	

	Instruction manual Series D multipole size 1	5000026173
		Version 01


6.3 Electrical characteristics

The multipolar D Series valve island requires a fixed 24Vdc (+/- 10%) power supply that is made through pins 24 (+) and 25 (-) of the 25-pin D-sub connector or pins 41-42 (+) and 43-44 (-) of the 44-pole connector.

The signals for activating the solenoid valves are PNP type, it is possible to activate a maximum of 22 solenoid pilots on 11 valve positions in the version with 25-pole connector and a maximum of 38 solenoid pilots on 19 valve positions in the version with 44-pole connector.

The multipolar D Series has a digital output (Pin 23 of the D-sub 25-pole connector or pin 40 of the D-sub 44-pole "open collector" diagnostic connector, the connection of the diagnostic output is optional

6.4 Adding a valve position or changing their position.




If it is necessary to add a valve position:

- Unscrew the screws (1) closing the right terminal (2) and open the valve pack
- Screw the tie rods in a single position up to the stop on the tie rods in the sub-bases (3)
- Insert the sub-base (4) on the tie rods paying attention to the connection between the card and the edgcard connector (5) and the correct positioning of the interface gasket between the sub-bases.
- Reassemble the right terminal (2) and tighten the screws (1) with **tightening torque 0.9 N.m**
- Screw the Series D valves onto the sub-bases with a tightening torque of 0.25 N.m**

	Instruction manual Series D multipole size 1	5000026173
		Version 01

6.5 Procedure for numbering the sub-bases / valve positions

The numbering procedure must be carried out in all those cases in which the sub-bases are added, removed or moved




To proceed with the numbering of the valve positions it is necessary to:

- to. Disconnect the power supply
- b. Remove the cap that covers the Reset button (1)
- c. Using a thin tip screwdriver, press and hold the Reset button
- d. Switch on the power and keep the Reset button pressed for 3 seconds
- is. Replace the cap that covers the Reset button (1)


Successful numbering is signaled by the simultaneous flashing of the LEDs on the sub-bases and the LED operating status (2)

Otherwise, that is, if the numbering was not correctly done, the red diagnostic LED (3) will light up, and the LED of the last valve position correctly numbered.

	Instruction manual Series D multipole size 1	5000026173
		Version 01


6.3 WLAN connection procedure:

Before connecting a D-Series island to a WLAN, it is necessary to have read the information and followed the instructions in "5000024829 - User manual UVIX.pdf" downloadable from the site <http://catalogue.camozzi.com/Downloads.aspx?cat=205>




The following steps are necessary to configure the WLAN connection:

- Check that the letter W is present in the sixth position of the code, e.g. DMC.W ...
- Remove the cap that covers the Reset button (1)
- Provide power to the island (operating status LED (2) flashing green), press the Reset button for at least 5 seconds.
- The island is configured as an Access Point and generates the "CamoZZiWiFi" WLAN network.
- Using a PC or portable device, connect to the "CamoZZiWiFi" network, access with the password "!! camozzi"
- Open a browser and connect to the address 192.168.1.1, where the following page (mini-app) will appear:



The screenshot shows a web browser window with the address bar displaying '192.168.1.1'. The page title is 'CamoZZi Automation'. Below the title, there are three input fields labeled 'SSID', 'Fep Address', and 'Password'. At the bottom of the form, there is a 'Save' button.

	Instruction manual Series D multipole size 1	5000026173
		Version 01


- g. Enter the credentials of the network to which you want to connect the island, for example:
 - a. SSID: camozziUVIX
 - b. FEP ADDRESS: 192.168.0.5
 - c. PASSWORD: camozziUVIX
- h. The valve island is configured as a Client and connects to the network for data transmission.
- i. Replace the cap that covers the Reset button (1)

COILVISION. DESCRIPTION OF THE PREDICTIVE DIAGNOSTIC SYSTEM AND DATA COLLECTION

The D Series valve island is able to send data, alarms and the health status of individual solenoid pilots via WLAN, allowing them to be monitored and predicted for wear and efficiency.

The data collected through an IoT Gateway are routed to the supervisory system called Camozzi UVIX.

CamoZZi UVIX is a software supervisor that can be installed on a PC or on a server inserted in a corporate network and accessible from other PCs. It allows you to view all the information of a network of Camozzi devices and all the data collected: from the general characteristics of the island (number of island valves, valve type) up to the health status of the individual valve (gauge indicator or alarm indicator).




The screenshot displays the Camozzi UVIX software interface. The top navigation bar includes the Camozzi logo, a notification icon with the number 4, and menu items for Setup, User Camozzi, Home, and About. The left sidebar lists 'CamoZZi Machines' with a tree view showing 'Durata KLD Nucleo Scaricato', 'Accelerata PLT BAT 1', 'Accelerata PLT BAT 2', and 'Temperatura'. The 'Temperatura' machine is selected, showing four 'double pilot' valves with green status indicators. Below this is a 'Summary' section for 'Temperatura PIC slaves status' showing 4 green, 0 yellow, and 0 red indicators.

The main content area shows details for 'Machine: TestLaboratorio', 'Device: Temperatura', and 'Slave: 1 - double pilot'. A 'Global Information' panel includes a device image with a 'Configuration' icon, and fields for 'Slave ID: 1', 'Typology: double pilot', 'Firmware: 1.25', 'Last transmission: 2019-06-05 08:43:18', 'Status: Work' (with a green dot), and 'Operational status: Work'. A 'Details' section is partially visible at the bottom.


	Instruction manual Series D multipole size 1	5000026173
		Version 01

The information on the health status of the individual solenoid valves mounted on the island is displayed by means of a gauge indicator with decreasing percentage based on a predictive algorithm.




7. CamozziUVIX: Series D configuration


7.1 Access to CamozziUVIX:



Access to CamozziUVIX can take place in "View" mode using the "enduser" user and the "enduser" password or in "Configuration" mode using the "user" user and the "customer" password.


	Instruction manual Series D multipole size 1	5000026173
		Version 01

7.2 : Assignment of the name and group to the Series D valve island



The system signals the presence of a new Series D island connected to the WLAN network click on the icon (1) to display the Serial number of the Series D island.

Click on the Serial number (2) to open the configuration screen




Assign an identifier to the device in the "Name" window (3)

Assign the device to a "Devices Group" (4) that must have been previously created


Save the configuration (5)

NOTE: Instructions for creating a Device Group (from file: 5000024829 - User manual UVIX.pdf)



Click on the Setup icon and select the "Devices Group" item

- **Devices Groups:** it is possible to add new device groups by specifying their name, or view and / or modify the device groups already present in the master data.



Description	
1	Button for creating a new group of devices
2	Button for ascending / descending alphabetical sorting
3	Filter of the values contained in the relative column
4	Buttons for viewing the details of the device group or changing its properties

	Instruction manual Series D multipole size 1	5000026173
		Version 01

Once the button **[1]** has been pressed, the following screen will be displayed:



Figura 14 – Devices group


After entering the required information (the mandatory ones are indicated with "*"), you can conclude the insertion of the new group of devices by clicking on the "Save" button located at the bottom right.

If the data is incorrect, the wrong fields are highlighted and a note describes the problem.

By selecting "TRUE" under "Decommissioned", the selected group of devices will no longer be available (and therefore will no longer be displayed in the left bar) while remaining present in the master data.

By pressing the display and / or edit buttons **[4]**, a screen similar to the previous one will be displayed.


7.3: General information and valve island status




The connected Series D valve island is displayed in the list of devices (6) on the left side of the screen. Click on the name to view the relative screen with general information (7), the status of the island (8), the "tabs" (9) for viewing:

- Temperature and supply voltage of the Series D island
- the status of the valve island alarms (see chapter "8. Fault identification"> Table "Master LED behavior")
- Controls (visible only if the access was made in "user" mode)

7.4 : Commands for configuring the valve island (only with "user" access)




After selecting the "Tab Comands" click on the "Send" button (10) to bring the Series D valve island to "Manual" mode



The valve island switches to manual mode (11) and the controls (12) appear on the screen

7.4.1 End manual mode: returns the valve island to the "automatic" state

7.4.2 Reset slave info: resets the state of health and the number of cycles performed by the valve which is mounted on a sub-base (see paragraph 7.5)



Click on the "Send" button (12) to reset the information saved in the sub-base


The information relating to the state of health of the valve and the number of operations performed by the single solenoid pilot is recorded by the sub-base on which the valve is mounted, should the replacement of a solenoid valve become malfunctioning or for which the system has highlighted a low state of health (preventive maintenance) it is necessary to reset this information.

In this way the system will resume recording only the information relating to the new valve fitted.

7.4.3 Set Digital Output: allows remote operation of the single coil of the valve island.


Warning: make sure that the solenoid valves are activated in total safety

In this mode the controls and commands of the PLC or control system are deactivated



Click on the "On" and "Off" keys to pilot the single solenoid pilot and to switch the solenoid coils.

7.5 General information and status of the individual solenoid coils




Click on the drop-down menu (13) to open the list of valves mounted on the Series D island and click on the valves (14) to display the content screen: general information (15), the health status of the individual solenoid pilot (16) , the Tabs for displaying (17):


- **Variables:** the variables (for example the number of operations) recorded for the valve mounted on the sub-base are displayed
- **Alarms:** the status of the alarms monitored for the single sub-base / valve is displayed (see chapter "8. Fault identification"> "Sub-base LED behavior" table)

7.6 Configurazione dei parametri della sottobase (solo con accesso “user”)

La configurazione dei parametri è possibile solo con l’isola di valvola in modalità manuale.



Cliccare sul tasto “Configuration” (18) (presente solo con accesso “user”) per entrare nella schermata di configurazione della singola sottobase/valvola.



From the configuration screen you can:

- Display PC parameters or parameters saved in the sub-base (19)
- Reset the status of the configured parameters (20)
- Save the parameter configuration in CamozziUVIX (21)
- Send the parameters to the sub-base (22): the parameters become operational but are not saved and reset if the valve island is turned off
- Save the parameters in the sub-base (23): saving the parameters in the sub-base, the parameters will be stored and maintained in case of shutdown of the valve island.
- Close the screen (24)

	<h1 style="text-align: center;">Instruction manual</h1> <h2 style="text-align: center;">Series D multipole size 1</h2>	5000026173
		Version 01

7.6.1 Set Alarms Enable: Enabling of the single alarm for each valve position



By clicking on the drop-down menu (25) it is possible to enable or disable the single alarm for the sub-base in configuration. If one of the events for which the alarm has been enabled occurs, an error message is sent.

The selectable alarms are:

- Non energized solenoid.
- Solenoid interrupted.
- Solenoid with anomalous current absorption or with excessive temperature.

Alarms are enabled by default.

6.5.1 Alarm mode:



For the single valve position it is possible to set the group of alarms as:

- Blocking (Default): the solenoid pilot in error is turned off and can no longer be piloted until the fault has been removed.
- Non-blocking: it is possible to set the single valve position so that the error generated by the solenoid pilot is signaled but the alarm is not blocking for the valve that will continue to operate.

NOTE: the system indicates with the icon (26) that the setting of the parameter in CamozziUVIX does not correspond to the state physically set in the sub-base

	Instruction manual Series D multipole size 1	5000026173
		Version 01

8. FAULT IDENTIFICATION

The Series D valve island has an OPEN COLLECTOR diagnostic output with which it signals the faults that may occur to the single valve / sub-base. The maximum controllable current is 50mA and is equipped with short circuit protection.

(Pin 23 of the 25-pin D-sub connector and Pin 39 of the 44-pin D-sub connector)

- Non energized solenoid.
- Solenoid interrupted.
- Solenoid with anomalous current absorption or with excessive temperature.

The status of this output depends on the type of alarm set:

Blocker (Default): the status of the diagnostic output is restored by removing the fault by turning the island off and on again.

Non-blocking: the status of the diagnostic output is restored by removing the fault or by driving OFF the solenoid that caused the problem

The sub-bases indicate the type of alarm by means of a coded flashing of the LED associated with the individual solenoid pilot (see following table).

COMPORTAMENTO LED SOTTOBASI

STATO	LED	COMPORTAMENTO	SIGNIFICATO
Solenoid Not Energized	● (Yellow)	Blinking (1 blink @100 ms every 1 s)	The solenoid is not energized.
Solenoid Interrupted	● (Yellow)	Blinking (2 blink @100 ms every 1 s)	The solenoid is interrupted (open circuit).
Solenoid Overcurrent or Overheating	● (Yellow)	Blinking (3 blink @100 ms every 1 s)	The solenoid is over the current threshold or it is over the heating threshold.
Subbase Overheating	● (Yellow)	Blinking (10 Hz)	The subbase is over the heating threshold.

	Instruction manual Series D multipole size 1	5000026173
		Version 01

COMPORTAMENTO LED MASTER:

STATO	LED	COMPORTAMENTO	SIGNIFICATO
Work (WLAN OFF)	<div>● (red)</div> <div>● (green)</div>	Off Blinking (1 blink @100 ms every 1s)	The valves island is in work status and the WLAN module (optional) is connection is NOT present or NOT connected
Work (WLAN ON)	<div>● (red)</div> <div>● (green)</div>	Off Blinking (1 blink @300 ms every 3 s)	The valves island is in work status and the WLAN module (optional) is present and connected
Work "Manual mode" (WLAN ON)	<div>● (red)</div> <div>● (green)</div>	Off Blinking (2 blink @300 ms every 3s)	The valves island is in work status and the WLAN module (optional) is connection is NOT present or NOT connected. The <u>valve island is in "manual mode" setted by UVIX</u>
Valve alarm	<div>● (red)</div> <div>● (green)</div>	Blinking (1 blink @100 ms every 1 s) Blinking	At least a valve has an alarm: <ul style="list-style-type: none"> - Subbase Overheating - Solenoid Overcurrent - Solenoid Overheating - Solenoid Not Energized - Solenoid Interrupted
Comunication Alarm	<div>● (red)</div> <div>● (green)</div>	Blinking (2 blink @100 ms every 1 s)	The left terminal (Master) has lost communication with the sub-bases
Under Voltage alarm	<div>● (red)</div> <div>● (green)</div>	Blinking (3 blink @100 ms every 1 s) Blinking	The power supply is under the voltage threshold.
Overheating Master	<div>● (red)</div> <div>● (green)</div>	Blinking (5 blink @100 ms every 1 s) Blinking	Overheating of the left terminal (Master)

	Instruction manual Series D multipole size 1	5000026173
		Version 01

Numbering Alarm	● (red)	Blinking (1 blink @100 ms every 1s)	The island is in error of numbering, it has never been put in communication with any sub-base Carry out the numbering procedure as per point 6.6
	● (green)	Off	
Mapping Alarm	● (red)	Blinking (2 blink @100 ms every 1 s)	The island is in a mapping error. The layout of the sub-bases has been changed, check it and if necessary repeat the numbering procedure as per point 6.6
	● (green)	Off	

9. USE

- Make sure that the voltage of the distribution network and that all operating conditions are within the admissible values.
- The product can be put into operation only in compliance with the specifications indicated, if these specifications are not respected the product can be put into operation only after authorization by Camozzi.
- Respect the indications on the identification plate.
- In case of prolonged stops longer than 3 months, before operating the system, carry out some empty maneuvers

10. USE LIMITATION

- Do not exceed the technical specifications shown in the "General characteristics" paragraph and in the Camozzi general catalog.
- Do not install the product in environments where the air itself can cause dangers.
- Unless specifically intended for use, do not use the product in environments where direct contact with corrosive gases, chemicals, salt water, water or steam could occur.

11. MAINTENANCE

- Incorrectly performed maintenance operations can compromise the correct functioning of the product and cause damage to surrounding people.
- Check the conditions to prevent the sudden release of pieces, then suspend the supply of power and allow the discharge of residual voltages before intervening.
- Check the possibility of having the product serviced at a technical assistance center.
- Never disassemble a live unit.
- Isolate the product electrically and pneumatically before maintenance.

	Instruction manual Series D multipole size 1	5000026173
		Version 01

- Always remove accessories before maintenance.
- Always make sure that you are wearing the correct safety equipment required by local authorities and by current laws.
- In case of maintenance, replacement of wear parts, use only original Camozzi kits and have the operation carried out only by authorized specialist personnel. Otherwise the product homologation loses all its validity.

12. ECOLOGICAL INFORMATION

- At the end of the product life cycle, the separation of materials is recommended to allow for their recovery.
- Comply with the regulations in force in your country regarding disposal.
- The product and the parts that compose it comply with ROHS, REACH regulations.

13. Contacts

Camozzi Automation SpA

Società Unipersonale

Via Eritrea, 20/I

25126 Brescia - Italy

Tel. +39 030 37921

Fax +39 030 2400464

info@camozzi.com

www.camozi.com

Product Certification

National and International Directives, Regulations and Standards

productcertification@camozzi.com

Technical assistance

Technical information

Product information

Special products

Tel.+39 030 3792390

service@camozzi.com