

**Table 1: mounting of sensors on cylinders**

Series	∅	CST - CSH	CSV	CSN
<b>24 - 25</b>	16	S-CST-02		
	20	S-CST-03		
	25	S-CST-04		
<b>27</b>	20	S-CST-03		
	25	S-CST-04		
	32	S-CST-18		
	40	S-CST-19		
	50	S-CST-20		
	63	S-CST-21		
<b>31</b>	12	Direct mounting		
	16	Direct mounting		
	20	Direct mounting		
	25	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
	50	Direct mounting		
	63	Direct mounting		
	80	Direct mounting		
	100	Direct mounting		
<b>32</b>	20	Direct mounting		
	25	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
	50	Direct mounting		
	63	Direct mounting		
	80	Direct mounting		
<b>40</b>	160	S-CST-28		S21
	200	S-CST-28		S21
	250			Direct mounting
	320			Direct mounting
<b>41</b>	160			S53
	200			S53
<b>42</b>	32	S-CST-18		
	40	S-CST-19		
	50	S-CST-20		
	63	S-CST-21		
<b>50</b>	16		Direct mounting	
	25		Direct mounting	
	32	S-CST-01		
	40	S-CST-01		
	50	S-CST-01		
	63	S-CST-01		
	80	S-CST-01		
<b>52</b>	25	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
	50	Direct mounting		
	63	Direct mounting		
<b>45N</b>	32	S-CST-45N1		
	40	S-CST-45N1		
	50	S-CST-45N1		
	63	S-CST-45N1		
	80	S-CST-45N2		
	100	S-CST-45N2		

**Table 2: mounting of sensors on cylinders**

Series	∅	CST - CSH
<b>61</b>	32	Direct mounting
	40	Direct mounting
	50	Direct mounting
	63	Direct mounting
	80	Direct mounting
	100	Direct mounting
<b>63...P</b>	32	Direct mounting (CSH only)
	40	Direct mounting (CSH only)
	50	Direct mounting (CSH only)
	63	Direct mounting (CSH only)
	80	Direct mounting (CSH only)
	100	Direct mounting (CSH only)
<b>63...T</b>	125	Direct mounting (CSH only)
	32	S-CST-25
	40	S-CST-25
	50	S-CST-25
	63	S-CST-25
	80	S-CST-26
<b>69</b>	100	S-CST-26
	125	S-CST-27
	32	Direct mounting
	40	Direct mounting
	50	Direct mounting
	63	Direct mounting
<b>6PF</b>	80	Direct mounting
	100	Direct mounting
	125	Direct mounting
	50	Direct mounting
	63	Direct mounting
	80	Direct mounting
<b>90</b>	100	Direct mounting
	125	Direct mounting
	32	S-CST-06
	40	S-CST-07
	50	S-CST-08
	63	S-CST-09
<b>94</b>	80	S-CST-10
	100	S-CST-11
	125	S-CST-12
<b>95</b>	16	S-CST-05
	20	S-CST-05
	25	S-CST-05
<b>97</b>	16	S-CST-05
	20	S-CST-05
	25	S-CST-06
<b>97</b>	32	S-CST-06
	40	S-CST-07
	50	S-CST-08
	63	S-CST-09

**Table 3: mounting of sensors on cylinders**

Series	∅	CST - CSH	CSV	CSC-D / CSC-H
<b>QC</b>	20	Direct mounting		
	25	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
	50	Direct mounting		
<b>QCBF</b>	20	Direct mounting		
	25	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
<b>QCTF</b>	20	Direct mounting		
	25	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
<b>QP - QPR</b>	12		Direct mounting	
	16		Direct mounting	
	20	S-CST-01		
	25	S-CST-01		
	32	S-CST-01		
	40	S-CST-01		
	50	S-CST-01		
	63	S-CST-01		
	80	S-CST-01		
	100	S-CST-01		
<b>QX</b>	10			Direct mounting
	16			Direct mounting
	20			Direct mounting
	25			Direct mounting
	32			Direct mounting
<b>ST</b>	20	Direct mounting		
	32	Direct mounting		
	40	Direct mounting		
	50	Direct mounting		

**Table 4: mounting of sensors on grippers, electromechanical axis/cylinders**

\* Further details about Series 5E electromechanical axis and Series 6E electromechanical cylinders can be found in the Electric actuation catalogue.

Series	Ø	CST - CSH	CSB-D / CSB-H	CSC-D / CSC-H	CSD-D / CSD-H
<b>Grippers</b>					
<b>CGA</b>	10		Direct mounting		
	16		Direct mounting		
	20		Direct mounting		
	25		Direct mounting		
	32		Direct mounting		
<b>CGC</b>	50		Direct mounting (CSB-D-220 only)		
	64		Direct mounting (CSB-D-220 only)		
	80		Direct mounting (CSB-D-220 only)		
	100		Direct mounting (CSB-D-220 only)		
	125		Direct mounting (CSB-D-220 only)		
<b>CGLN</b>	10			Direct mounting	
	16			Direct mounting	
	20			Direct mounting	
	25			Direct mounting	
	32			Direct mounting	
<b>CGP</b>	10		Direct mounting		
	16		Direct mounting		
	20		Direct mounting		
	25		Direct mounting		
	32		Direct mounting		
<b>CGPS</b>	10				Direct mounting
	16				Direct mounting
	20				Direct mounting
	25				Direct mounting
	32				Direct mounting
<b>CGPT</b>	16				Direct mounting
	20				Direct mounting
	25				Direct mounting
	32				Direct mounting
	40				Direct mounting
<b>CGSN</b>	16			Direct mounting	Direct mounting
	20			Direct mounting	Direct mounting
	25			Direct mounting	Direct mounting
	32			Direct mounting	Direct mounting
<b>RPGB</b>	8				Direct mounting
	12				Direct mounting
<b>Electromechanical axis *</b>					
<b>5E</b>	50	Direct mounting (CSH only)			
	65	Direct mounting (CSH only)			
	80	Direct mounting (CSH only)			
<b>Electromechanical cylinders *</b>					
<b>6E</b>	32	Direct mounting			
	40	Direct mounting			
	50	Direct mounting			
	63	Direct mounting			