

## Assembly configurator - Series MD

Product code: MD1-AV-6

Datasheet creation date: 10/03/2025 01:05

Check the most updated document online [click here](#)



### TECHNICAL DATA

Series	MD
Connection type	GAS
Input	Ø6
Output	Ø6
Flow direction	from left to right
Function	AV =Soft start valve
FN01A	
FN01B	
FN01C	
FN01D	
AC01A	-
AC01B	
AC01C	
Function description	Soft start valve
Function	-
FN02A	
FN02B	
FN02C	
FN02D	
AC02A	

## Assembly configurator - Series MD

Product code: MD1-AV-6

### **DIMENSIONS**

<b>Series</b>	MD
<b>Connection type</b>	GAS
<b>Input</b>	Ø6
<b>Output</b>	Ø6
<b>Flow direction</b>	from left to right
<b>Function</b>	AV =Soft start valve
<b>FN01A</b>	
<b>FN01B</b>	
<b>FN01C</b>	
<b>FN01D</b>	
<b>AC01A</b>	-
<b>AC01B</b>	
<b>AC01C</b>	
<b>Function description</b>	Soft start valve
<b>Function</b>	-
<b>FN02A</b>	
<b>FN02B</b>	
<b>FN02C</b>	
<b>FN02D</b>	
<b>AC02A</b>	
<b>AC02B</b>	
<b>AC02C</b>	
<b>Function description</b>	

<b>Function</b>	
<b>FN03A</b>	
<b>FN03B</b>	
<b>FN03C</b>	
<b>FN03D</b>	
<b>AC03A</b>	
<b>AC03B</b>	
<b>AC03C</b>	
<b>Function description</b>	
<b>Function</b>	
<b>FN04A</b>	
<b>FN04B</b>	
<b>FN04C</b>	
<b>FN04D</b>	
<b>AC04A</b>	
<b>AC04B</b>	
<b>AC04C</b>	
<b>Function description</b>	
<b>Function</b>	
<b>FN05A</b>	
<b>FN05B</b>	
<b>FN05C</b>	
<b>FN05D</b>	