

## Assembly configurator - Series MD

Product code: MD1-V16-3/8

Datasheet creation date: 10/03/2025 01:12

Check the most updated document online [click here](#)



### TECHNICAL DATA

|                      |   |
|----------------------|---|
| Series               | MD  |
| Connection type      | GAS   |
| Input                | G3/8  |
| Output               | G3/8  |
| Flow direction       | from left to right  |
| Function             | V = Valve 3/2 ways  |
| FN01A                | 16 = electro-pneumatic control, Push & Turn manual override             |
| FN01B                |   |
| FN01C                |   |
| FN01D                |   |
| AC01A                | -   |
| AC01B                | -   |
| AC01C                | -   |
| Function description | 3/2 NC way valve electro-pneumatic control, Push & Turn manual override |
| Function             | -   |
| FN02A                |   |
| FN02B                |   |
| FN02C                |   |
| FN02D                |   |
| AC02A                |   |

## Assembly configurator - Series MD

Product code: MD1-V16-3/8

### **DIMENSIONS**

|                             |   |
|-----------------------------|---|
| <b>Series</b>               | MD  |
| <b>Connection type</b>      | GAS   |
| <b>Input</b>                | G3/8  |
| <b>Output</b>               | G3/8  |
| <b>Flow direction</b>       | from left to right  |
| <b>Function</b>             | V = Valve 3/2 ways  |
| <b>FN01A</b>                | 16 = electro-pneumatic control, Push & Turn manual override             |
| <b>FN01B</b>                |   |
| <b>FN01C</b>                |   |
| <b>FN01D</b>                |   |
| <b>AC01A</b>                | -   |
| <b>AC01B</b>                | -   |
| <b>AC01C</b>                | -   |
| <b>Function description</b> | 3/2 NC way valve electro-pneumatic control, Push & Turn manual override |
| <b>Function</b>             | -   |
| <b>FN02A</b>                |   |
| <b>FN02B</b>                |   |
| <b>FN02C</b>                |   |
| <b>FN02D</b>                |   |
| <b>AC02A</b>                |   |

|                             |  |
|-----------------------------|--|
| <b>AC02B</b>                |  |
| <b>AC02C</b>                |  |
| <b>Function description</b> |  |
| <b>Function</b>             |  |
| <b>FN03A</b>                |  |
| <b>FN03B</b>                |  |
| <b>FN03C</b>                |  |
| <b>FN03D</b>                |  |
| <b>AC03A</b>                |  |
| <b>AC03B</b>                |  |
| <b>AC03C</b>                |  |
| <b>Function description</b> |  |
| <b>Function</b>             |  |
| <b>FN04A</b>                |  |
| <b>FN04B</b>                |  |
| <b>FN04C</b>                |  |
| <b>FN04D</b>                |  |
| <b>AC04A</b>                |  |
| <b>AC04B</b>                |  |
| <b>AC04C</b>                |  |
| <b>Function description</b> |  |
| <b>Function</b>             |  |
| <b>FN05A</b>                |  |